ORDER NO. SD82032141C8

Service Manual

Stereo Integrated Amplifier

SU-Z45

[E],[EG],[EK],[EF],[EH],
[EB],[Ei],[XA],[XL]

SU-Z45(K)

[E],[EG],[EH],[Ei]



* The cabinet and front panel are available in black color and silver types.
* The black type model is provided with (K) in the Service Manual.

Areas

* [E] is available in Scandinavia and Switzerland.
* [EG] is available in F.R. Germany.
* [EK] is available in United Kingdom.
* [EF] is available in France.
* [EH] is available in Holland.
* [EB] is available in Belgium.
* [Ei] is available in Italy.
* [XA] is available in Southeast Asia, Oceania, Africa, Middle Near East and Central South America.
* [XL] is available in Australia.

Specifications

(Specifications are subject to change without notice for further improvement.)

(DIN 45 500)

■ AMPLIFIER SECTION

20 Hz~20 kHz continuous power output	2 × 35W (4Ω)
both channels driven	2 × 35W (8Ω)
40 Hz~16 kHz continuous power output	2 × 35W (4Ω)
both channels driven	2 × 35W (8Ω)
1 kHz continuous power output	2 × 40W (4Ω)
both channels driven	2 × 40W (8Ω)
Total harmonic distortion	
rated power at 20 Hz~20 kHz	0.05% (4Ω), 0.03% (8Ω)
rated power at 40 Hz~16 kHz	0.05% (4Ω), 0.03% (8Ω)
rated power at 1 kHz	0.007% (4Ω), 0.005% (8Ω)
half power at 20 Hz~20 kHz	0.03% (8Ω)
half power at 1 kHz	0.005% (8Ω)
−26 dB power at 1 kHz	0.01% (4Ω)
50 mW power at 1 kHz	0.01% (4Ω)
Intermodulation distortion	
rated power at 250 Hz: 8 kHz=4:1, 4Ω	0.05%
rated power at 60 Hz: 7 kHz=4:1, SMPTE, 8Ω	0.03%
Power bandwidth	
both channels driven, −3 dB	10 Hz~25 kHz (4Ω)
	10 Hz~25 kHz (8Ω)
Residual hum and noise	0.6 mV
Damping factor	20 (4Ω), 40 (8Ω)
Input sensitivity and impedance	
PHONO	2.5 mV/47kΩ
TUNER, AUX	150 mV/22kΩ
TAPE 1	150 mV/22kΩ
TAPE 2	150 mV/22kΩ
PHONO maximum input voltage (1 kHz, RMS)	150 mV
Frequency response	
PHONO	RIAA standard curve ±0.8 dB (30 Hz~15 kHz)
TUNER, AUX, TAPE	5 Hz~80 kHz (−3 dB)
S/N	
rated power (4Ω)	
PHONO	75 dB (IHF, A: 81 dB)
TUNER, AUX, TAPE	86 dB (IHF, A: 97 dB)
26 dB power (4Ω)	
PHONO/TUNER, AUX, TAPE	65 dB/65 dB
50 mW power (4Ω)	
PHONO/TUNER, AUX, TAPE	62 dB/62 dB
Tone controls	
BASS	50 Hz, +10 dB~−10 dB
TREBLE	20 kHz, +10 dB~−10 dB
Loudness control (volume at −30 dB)	50 Hz, +9 dB
Output voltage	
REC OUT	150 mV
Channel balance, AUX 250 Hz~6,300 Hz	±1 dB
Channel separation, AUX 1 kHz	50 dB
Headphones output level and impedance	390 mV/330Ω
Load impedance	
MAIN or REMOTE/MAIN and REMOTE	4Ω~16Ω/8Ω~16Ω

■ GENERAL

Power consumption	310W
Power supply	AC 50 Hz/60 Hz, 220V (For continental Europe) AC 50 Hz/60 Hz, 240V (For United Kingdom and Australia) AC 50 Hz/60 Hz, 110V/120V/220V/240V (For others)
Dimensions (W × H × D)	430 × 86 × 288 mm (16-15/16" × 3-3/8" × 11-11/32")
Weight	5.8 kg (12.8 lb.)

Note:
Total harmonic distortion is measured by the digital spectrum analyzer (H.P. 3045 system).

Technics

Matsushita Electric Trading Co., Ltd.
P.O. Box 288, Central Osaka Japan

SU-Z45

■ CONTENTS

	Page
LOCATION OF CONTROLS	2
PROTECTION CIRCUITRY	3
BEFORE REPAIR AND ADJUSTMENT	3
TECHNICAL GUIDE	4
DISASSEMBLY INSTRUCTIONS	5
ADJUSTMENTS	7
PRINTED CIRCUIT BOARDS	8
TERMINAL GUIDE OF TRANSISTORS, DIODES AND IC'S	8
BLOCK DIAGRAM	11
HOW TO REPLACE CHIPS (RESISTORS)	12
SCHEMATIC DIAGRAM	13
REPLACEMENT PARTS LIST	17
EXPLODED VIEW	18
RESISTORS AND CAPACITORS	20

■ LOCATION OF CONTROLS





- The power supply for this unit varies depending upon the areas. Also, the parts used for power supply are different. So, refer to the circuit diagram and the replacement parts list.

* 220V (50/60Hz) for continental Europe.
* 240V (50/60Hz) for United Kingdom and Australia.
* 110V/120V/220V/240V (50/60Hz) for other areas.
– [XA area] for other areas is provided with voltage selector and AC outlets.
* Phono input capacitance is about 150pF.

ORDER NO. SD82060101P8

Parts Change Notice

File this bulletin with your Service manual

MODEL NO: SU-Z45 [E],[EG],[EK],[EF],[EH],[EB],[Ei],[XA],[XL]
SU-Z45(K) [E],[EG],[EH],[Ei]

ORDER NO: SD82032141C8

FILE No. SU-Z45 [E]-1

Subject: Change of Parts Number.

Please revise the original parts list in the Service Manual to conform to the change(s) shown herein. If new part numbers are shown, be sure to use them when ordering parts.

❶ Reason for Change	
[1] Improve performance	
[2] Change of material	
[3] Change of dimension	
[4] To meet approved specification	
[5] Standardization	
[6] Addition	
[7] Deletion	
[8] Correction	
[9] Other ( )	

❷ Interchangeability Code		
	Parts / Set Production	
[A]	Original → Early, New → Late	Original or new parts may be used in early or late production set. Use original parts until exhausted, then stock new parts.
[B]	Original → Early, New → Late	Original parts may be used in early production sets only. New parts may be used in early or late production sets. Use original parts where possible, then stock new parts.
[C]	Original → Early, New → Late	New parts only may be used in early or late production sets. Stock new parts.
[D]	Original → Early, New → Late	Original parts may be used in early production sets only. New parts may be used in late production sets only. Stock both original and new parts.

Part Number

❶	❷	Ref. No.	Original Part No.	New Part No.	Part Name & Descriptions
[8]	[—]	F1	XBA2C10TRO	XBA2C20TRO	Fuse, 250V, T2A
[8]	[—]	F2 [XA] only	XBA2C20TRO	XBA2C10TRO	Fuse, 250V, T1A
[ ]	[ ]				
[ ]	[ ]				
[ ]	[ ]				
[ ]	[ ]				
[ ]	[ ]				

Technics

Matsushita Electric Trading Co., Ltd.
P.O. Box 288, Central Osaka Japan
Printed in Japan
82060850 ® NT

ORDER NO. SD82062211C9

Service Manual

Stereo Integrated Amplifier

SU-Z45

[XV], [PA], [PE], [PC]

SU-Z45(K)

[XA] , [PC]

Areas

* [PA] is available in fer East PX.
* [PE] is available in European Military.
* [PC] is available in European Audio Club.
* [XV] is available in Venezuela.
* [XA] is available in Southeast Asia, Oceania, Africa, Middle Near East and Central South America.

* The cabinet and front panel are available in black color and silver types.
* The black type model is provided with (K) in the Service Manual.

* Please use this manual together with the service manual for Model No. SU-Z45 [E, EG , EK, EF, EH, EB, Ei, XA and XL areas] , Order No. SD82032141C8.
* Mentioned in this parts list are only those changed in Model No. SU-Z45 for destination [E] area.

CHANGES

■ REPLACEMENT PARTS LIST

Ref. No.		Change of Part No. SU-Z45 (E)	Change of Part No. SU-Z45 (PA,PE,PC,XA,XV)	Part Name & Description
Electronic Parts				
T1		SLT5M219	SLT5M223	Transformer, Power
F2		Addition	XBA2C10TRO	Fuse, T1A (250V)
S8		ESB822S	ESB90227S	Switch, Power
S9		Addition	ESE37219	Switch, Voltage Selector
Cabinet and Chassis Parts				
2	O	SYW573	SYW573—2	Front Panel Ass'y (Silver)
	(K)	SYW573—1	SYW573—3	Front Panel Ass'y (Black)
13		SMX609	SMX453	Shield Cover
13		SJT347	Deletion	Holder, Fuse
21		Addition	SJT347	Holder, Fuse
26		SJA88	SJA111 (XA,XV,PC) only	AC Cord
			RJA52Z (PA,PE) only	

Ref. No.	Change of Part No. SU-Z45 (E)	Change of Part No. SU-Z45 (PA,PE,PC,XA,XV)	Part Name & Description
28	SGP3170B	SGP3170—1A (XA,XV,PC) only	Rear Panel
		SGP3170—3A (PA,PE) only	
29	Addition	SJS601—2	Socket, AC Outlet
Accessories			
A1	Addition	SJP5213—1 (XA,XV,PC) only	Plug Adapter (C→U)
A2	Addition	SJP5215 (XA,XV,PC) only	Plug Adapter (U→B)
A3	Addition	RJP120ZBS (PA,PE) only	Plug Adapter
A4	SQF11213	SQF11221 (XA,PC) only	Instructions Book
		SQF11393 (XV) only	Instructions Book
		SQF11223 (PA,PE) only	Instructions Book

Technics
Panasonic Tokyo
Matsushita Electric Industrial Co., Ltd.
1-2, 1-chome, Shibakoen, Minato-ku, Tokyo 105 Japan
Matsushita Electric Trading Co., Ltd.
P.O. Box 288, Central Osaka Japan

■ REPLACEMENT PARTS LIST

Notes: 1. Part numbers are indicated on most mechanical parts. Please use this part number for parts orders.
2. Important safety notice:
Components identified by ⚠ mark have special characteristics important for safety.
When replacing any of these components use only manufacturer's specified parts.
3. Bracketed indications in Ref. No. columns specify the area.
Parts without these indications can be used for all areas.
4. The "**S**" mark is service standard parts and may differ from production parts.
5. The parenthesized numbers in the column of description stand for the quantity per set.
6. [K] -marked parts are used for black only, while ○-marked parts are for silver type only.
7. Parts other than [K] - and ○- marked are used for both black ans silver types.

Black type model No. SU-Z45 (K)

Ref. No.	Part No.	Description
INTEGRATED CIRCUITS		
IC1	SVINJM2043DD	Equalizer
(IC21)×2	AN7060F	Voltage AMP.
IC301	SVISTK2038B	Power AMP.
IC601, 602	SVIHA12010	Level Comparator
IC603	SVITA7318P	Meter AMP.
TRANSISTORS		
(Q20)×2	2SA1123—R	Pre Drive
Q41~43	2SA1015—Y	Switching/Hold
Q44	2SC1815—Y	Hold
Q401 **S**	2SA722—S	LED Drive
Q601 **S**	2SC1384AR	Regulator
DIODES		
(D21)×2, 41, 42 **S**	MA162A	Switching
D301	SVDMZ306A	6V, Zener
D401~404 ⚠	SVDS2V20	Rectifier
D405, 406 **S**	MA1150A	15V, Zener
D407, 413 ⚠**S** 414	SVDSR1K2	Rectifier
D408~410	LN31GCPHL	Light Emitting Diode
D411, 412	LN41YCP	Light Emitting Diode
D601	MA1200	20V, Zener
COILS		
L301, 302	SLQY15G—30	Choke
TRANSFORMERS		
T1 ⚠	SLT5M223	Power Source
VARIABLE RESISTORS		
VR201	EWJG2A052B15	Volume, 100kΩ (B)
VR202	EWHFKA004G15	Balance, 100kΩ (G)
VR301	EWCX9A005012	Treble
VR302	EWCXAA005C15	Bass, 100kΩ(C)
VR601, 602	EVNK6AA00B23	FL Level Meter, 2kΩ(B)
THERMISTORS		
TH301, 302	RRT104	100kΩ
COMPONENT COMBINATION		
Z401	SXRFS203ZSM	(0.01μF)×2
FLUORESCENT DISPLAY TUBE		
FL	SADBG89Z	Power Meter
FUSES		
F1 ⚠	XBA2C20TRO	250V, T2A
F2 ⚠	XBA2C10TRO	250V, T1A
SWITCHES		
S1	SSH3033	Input Selector
S2, 3, 4	SSH3043	Tape Monitor, Loudness
S5, 6	SSH2017	Speaker (Main/Remote)
S7	SSH1053	Range Selector
S8 ⚠	ESB90227S	Power Source
S9 ⚠	ESE37219	Voltage Selector

Ref. No.	Part No.	Description & Pcs
CABINET and CHASSIS PARTS		
1	SBN1089	Knob, Bass, Treble and Balance (3)
2 ○	SYW573—2	Front Panel Ass'y (Silver) (1)
2 [K]	SYW573—3	Front Panel Ass'y (Black) (1)
3	SBN1125	Knob, Volume (1)
4 ○	SGXUZ45E	Holder, Input Selector (Silver) (1)
4 [K]	SGXUZ45KE	Holder, Input Selector (Black) (1)
5 ○	SGXUZ45E1	Holder, Tape (Silver) (1)
5 [K]	SGXUZ45KE1	Holder, Tape (Black) (1)
6	SBC443	Button, Input Selector (3)
7	SBC445	Button, Tape Monitor (2)
8	SBC441	Button, Speaker, Range, Loudness (4)
9 ○	SDU131	Filter, FL (Silver) (1)
9 [K]	SDU131—1	Filter, FL (Black) (1)
10	SGX7327	Holder, FL (1)
11	SBC337—1	Button, Power Source (1)
12	SMX617	Shield Cover (1)
13	SMX453	Shield Cover (1)
15	SJJ71B	Jack, Headphone (1)
16 ○	SKC1050S1	Cabinet (Silver) (1)
16 [K]	SKC1050B1	Cabinet (Black) (1)
17	SUS275	Bracket (1)
18	SMP323—1	Holder, LED (Tape) (1)
19	SMP321—1	Holder, LED (Input) (1)
20	SMX365	Shield Cover (1)
21	SJT347	Holder, Fuse (4)
23	SML129	Bracket, Power Trasformer (1)
24	SMX615	Shield Cover (1)
25	SJF4815	Terminal Board (1)
26 ⚠ [XA, XV, PC]	SJA111	AC Cord (1)
26 ⚠**S** [PA, PE]	RJA52Z	AC Cord (1)
27	SHR127	Bushing, AC Cord (1)
28 [XA, XV, PC]	SGP3170—1A	Rear Panel (1)
28 [PA, PE]	SGP3170—3A	Rear Panel (1)
29 ⚠	SJS601—2	Socket (1)
30	SJF3051—3N	Terminal Board (1)
31	SHR401—1	Look Pin (1)
32	SKUUZ45E	Bottom Board (1)
33	SKL249	Foot (4)
SCREWS		
N1	XTBS3+8BFYR1	Tapping, with Detent (3)
N2 **S**	XTB3+8BFN	Tapping, ⊕3×8 (5)
N3 **S**	XSN3+6S	⊕3×6 (4)
N4 ○	SNE2095—2	Tapping (2)
N4 [K]	SNE2095—3	Tapping (2)

Ref. No.	Part No.	Description & Pcs
N5 **S**	XTB4+10BFZ	Tapping, ⊕×10 (4)
N6 **S**	XSN3+12BNS	⊕3×12 (2)
N7 **S**	XTN3+8B	Tapping, ⊕3×8 (1)
N9 **S** ○	XTB3+8BFN	Tapping, ⊕3×8 (2)
N9 **S**[K]	XTB3+8BFZ	Tapping, ⊕3×8 (2)
N10	XTBS3+8BFZ1	Tapping with Detent (10)
N12	XTBS3+8BFYR1	Tapping with Detent (2)
N13 **S**	XTN3+10B	Tapping, ⊕3×10 (4)
WASHERS		
N14 **S**	XWA38	Spring, ϕ3 (6)
N15 **S**	XWG3	Plain, ϕ3 (7)
N17 **S**	XWC3B	External Toothed Lock ϕ3 (2)
NUTS		
N18	SNE4021	Nut, with Plain (4)
N19 **S**	XNS12	ϕ12 (1)
ACCESSORIES		
A1 ⚠ [XA, XV, PC]	SJP5213—1	Plug Adapter, (C→U) (1)
A2 ⚠ [XA, XV, PC]	SJP5215	Plug Adapter, (U→B) (1)
A3 ⚠ [PA, PE]	RJP120ZBS	Plug Adapter (1)
A4 [XA, PC]	SQF11221	Instructions Book (1)
A4 [XV]	SQF11393	Instructions Book (1)
A4 [PA, PE]	SQF11223	Instructions Book (1)
PACKING PARTS		
P1 ○	SPP699	Polyethylene Bag (Silver) (1)
P1 [K]	SPP649	Polyethylene Bag (Black) (1)
P2	SPS3661—2	Pad, Left Side (1)
P3	SPS3663	Pad, Right Side (1)
P4 ○	SPG3895	Carton Box (Silver) (1)
P4 [K]	SPG3995	Carton Box (Black) (1)

■ POWER SOURCE CIRCUITRY





ORDER NO. SD82060101P8

Parts Change Notice

File this bulletin with your Service manual

MODEL NO: SU-Z45 [E],[EG],[EK],[EF],[EH],[EB],[Ei],[XA],[XL]
SU-Z45(K) [E],[EG],[EH],[Ei]

ORDER NO: SD82032141C8

FILE No. SU-Z45 [E]-1

Subject: Change of Parts Number.

Please revise the original parts list in the Service Manual to conform to the change(s) shown herein. If new part numbers are shown, be sure to use them when ordering parts.

❶ Reason for Change

1	Improve performance
2	Change of material
3	Change of dimension
4	To meet approved specification
5	Standardization
6	Addition
7	Deletion
8	Correction
9	Other ( )

❷ Interchangeability Code

Parts	Set Production	
A	Original → Early New → Late	Original or new parts may be used in early or late production set. Use original parts until exhausted, then stock new parts.
B	Original → Early New → Late	Original parts may be used in early production sets only. New parts may be used in early or late production sets. Use original parts where possible, then stock new parts.
C	Original → Early New → Late	New parts only may be used in early or late production sets. Stock new parts.
D	Original → Early New → Late	Original parts may be used in early production sets only. New parts may be used in late production sets only. Stock both original and new parts.

Part Number

❶	❷	Ref. No.	Original Part No.	New Part No.	Part Name & Descriptions
8	—	F1	XBA2C10TRO	XBA2C20TRO	Fuse, 250V, T2A
8	—	F2 [XA] only	XBA2C20TRO	XBA2C10TRO	Fuse, 250V, T1A

Technics

Matsushita Electric Trading Co., Ltd.
P.O. Box 288, Central Osaka Japan
Printed in Japan
82060850 ®NT

ORDER NO. SD82032141C8–A

DEUTSCH

Stereo Integrated Amplifier SU-Z45/SU-Z45(K)

This booklet contains the specifications and adjusting procedures for SU-Z45, written in Germany, Franch and Spanish, and the circuits to be changed according to the areas.
File this manual together with the SU-Z45 service manual (Order No. SD82032141C8).

DEUTSCH

■ TECHNISCHE DATEN (Spezifikationen Können infolge von Verbesserungen ohne Ankündigung geändert werden.)

(DIN 45 500)

■ VERSTÄRKERTEIL

Dauerton-Ausgangsleistung bei 20 Hz ~ 20 kHz
beide Kanäle ausgesteuert 2 × 35W (4 Ω), 2 × 35W (8 Ω)
Dauerton-Ausgangsleistung bei 40 Hz ~ 16 kHz
beide Kanäle ausgesteuert 2 × 35W (4 Ω), 2 × 35W (8 Ω)
Dauerton-Ausgangsleistung bei 1 kHz
beide Kanäle ausgesteuert 2 × 40W (4 Ω), 2 × 40W (8 Ω)
Gesamtklirrfaktor
Nennleistung bei 20 Hz ~ 20 kHz 0,05% (4 Ω), 0,03% (8 Ω)
Nennleistung bei 40 Hz ~ 16 kHz 0,05% (4 Ω), 0,03% (8 Ω)
Nennleistung bei 1 kHz 0,007% (4 Ω), 0,005% (8 Ω)
halbe Nennleistung bei 20 Hz ~ 20 kHz 0,03% (8 Ω)
halbe Nennleistung bei 1 kHz 0,005% (8 Ω)
−26 dB Leistung bei 1 kHz 0,01% (4 Ω)
50 mW Leistung bei 1 kHz 0,01% (4 Ω)
Intermodulationsfaktor
Nennleistung bei 250 Hz: 8 kHz = 4:1, 4 Ω 0,05%
Nennleistung bei 60 Hz: 7 kHz = 4:1, nach SMPTE, 8 Ω 0,03%
Leistungsbandbreite
beide Kanäle ausgesteuert bei −3 dB
10 Hz ~ 25 kHz (4 Ω), 10 Hz ~ 25 kHz (8 Ω)
Restbrumm und Geräusch 0,6 mV
Dämpfungsfaktor 20 (4 Ω), 40 (8 Ω)
Eingangsempfindlichkeit und -impedanz
Phono 2,5 mV/47 kΩ
Tuner, Aux 150 mV/22 kΩ
Tape 1 (TAPE 1) 150 mV/22 kΩ
Tape 2 (TAPE 2) 150 mV/22 kΩ
Maximale TA-Eingangsspannung (1 kHz, eff.) 150 mV
Frequenzgang
Phono RIAA-Standardkurve, ±0,8 dB (30 Hz ~ 15 kHz)
Tuner, Aux, Tape 5 Hz ~ 80 kHz (−3 dB)
Geräuschabstand
Nennleistung (4 Ω)
Phono 75 dB (nach IHF, A: 81 dB)
Tuner, Aux, Tape 86 dB (nach IHF, A: 97 dB)
−26 dB Leistung (4 Ω)
Phono 65 dB
Tuner, Aux, Tape 65 dB
50 mW Leistung (4 Ω)
Phono 62 dB
Tuner, Aux, Tape 62 dB
Klangregler
Baßregler (BASS) 50 Hz, +10 dB ~ −10 dB
Höhenregler (TREBLE) 20 kHz, +10 dB ~ −10 dB
Gehörrichtige Lautstärkekorrektur (Loudness)
(bei −30 dB Ausgangsleistung) 50 Hz, +9 dB
Ausgangsspannung und -impedanz
Aufnahmeausgang (REC OUT) 150 mV
Kanalabweichung (Aux, 250 Hz ~ 6.300 Hz) ±1 dB
Übersprechdämpfung (Aux, 1 kHz) 50 dB
Kopfhörerpegel und -impedanz 390 mV/330 Ω
Lautsprecherimpedanz
MAIN oder REMOTE 4 Ω ~ 16 Ω
MAIN und REMOTE 8 Ω ~ 16 Ω

■ ALLGEMEINE DATEN

Leistungsaufnahme 310 W
Netzspannung Wechselstrom 50 Hz/60 Hz, 220V (Für Kontinentaleuropa)
Wechselstrom 50 Hz/60 Hz, 110V/120V/220V/240V (Für andere Länder)
Abmessungen (B×H×T) 430 × 86 × 288 mm
Gewicht 5,8 kg

Bemerkung:
Der Gesamtklirrfaktor wurde mit einem digitalen Rauschspektrometer (Anlage H.P. 3045) gemessen.

■ JUSTIERUNGEN

Spitzenwertanzeigen

Einstellung:

- Einen Niederfrequenzoszillator an die Eingangsklemme des Tuners schließen und parallel zu 8-ohm Belastungswiderstand den elektronischen Wechselstrom-Voltmeter an die Lautsprecherklemme schließen.
- 1 kHz Signal aus dem Niederfrequenzoszillator in das Gerät speisen.
- Lautstärkeregler auf den minimalen Punkt einstellen.

Gegenstand	Stellung des Meterbereichswählers	Zu justierender widerstand	Justierung
Spitzenwertanzeigen	Bereichswähler auf X0.01	VR601 (Linker Kanal) VR602 (Rechter K.)	1. Den Eingangspegel so justieren, daß der Wechselstrom-Voltmeter 2,0V anzeigt. 2. Die halbfest eingestellten Widerstände VR601 (linker Kanal) und VR602 (rechter Kanal) so einstellen, daß das 50W -Segment des Fluoreszenz-Aussteuerungsinstru-mentes schwach aufleuchtet. (Abb. 14)

FRANÇAIS

■ CARACTERISTIQUES (Sujet à changement sans préaris.)

(DIN 45 500)

■ SECTION AMPLIFICATEUR

Puissance de sortie continue de 20 Hz~20 kHz,	2 × 35W (4Ω)
les deux canaux en circuit	2 × 35W (8Ω)
Puissance de sortie continue de 40 Hz~16 kHz,	2 × 35W (4Ω)
les deux canaux en circuit	2 × 35W (8Ω)
Puissance de sortie continue à 1 kHz	2 × 40W (4Ω)
les deux canaux en circuit	2 × 40W (8Ω)
Distorsion harmonique totale	
à puissance nominale (20 Hz~20 kHz)	0,05% (4Ω)
	0,03% (8Ω)
à puissance nominale (40 Hz~16 kHz)	0,05% (4Ω)
	0,03% (8Ω)
à puissance nominale (1 kHz)	0,007% (4Ω)/0,005% (8Ω)
à demi-puissance (20 Hz~20 kHz)	0,03% (8Ω)
à demi-puissance (1 kHz)	0,005% (8Ω)
puissance de −26 dB à 1 kHz	0,01% (4Ω)
puissance de 50 mW à 1 kHz	0,01% (4Ω)
Distorsion d'intermodulation	
à puissance nominale à 250 Hz: 8 kHz=4:1, 4Ω	0,05%
à puissance nominale à 60 Hz: 7 kHz=4:1, SMPTE, 8Ω	0,03%
Réponse de fréquences	
les deux canaux en circuit, −3 dB	10 Hz~25 kHz (4Ω)
	10 Hz~25 kHz (8Ω)
Bruit et ronflement résiduels	0,6 mV
Coefficient d'amortissement	20 (4Ω), 40 (8Ω)
Sensibilité et impédance d'entrée	
PHONO	2,5 mV/47kΩ
SYNTONISATEUR, AUX (TUNER, AUX)	150 mV/22kΩ
BANDE 1 (TAPE 1)	150 mV/22kΩ
BANDE 2 (TAPE 2)	150 mV/22kΩ
PHONO (tension d'entrée maximum, 1 kHz RMS)	150 mV
Réponse de fréquence	
PHONO Courbe nominale RIAA/±0,8 dB (30 Hz~15 kHz)	
SYNTONISATEUR, AUX, BANDE (TUNER, AUX, TAPE)	5 Hz~80 kHz (−3 dB)
Réglage de la tonalité	
BASSES (BASS)	50 Hz, +10 dB~ −10 dB
AIGUS (TREBLE)	20 kHz, +10 dB~ −10 dB
Compensateur physiologique (volume à −30 dB)	50 Hz, +9 dB
Signal/Bruit	
à puissance nominale (4Ω)	
PHONO	75 dB (IHF, A: 81 dB)
SYNTONISATEUR, AUX, BANDE (TUNER, AUX, TAPE)	86 dB (IHF, A: 97 dB)
puissance de −26 dB (4Ω)	
PHONO	65 dB
SYNTONISATEUR, AUX, BANDE (TUNER, AUX, TAPE)	65 dB
puissance de 50 mW (4Ω)	
PHONO	62 dB
SYNTONISATEUR, AUX, BANDE (TUNER, AUX, TAPE)	62 dB
Tension de sortie et impédance	
SORTIE ENREGISTREMENT (REC OUT)	150 mV
Equilibrage des canaux, AUX 250 Hz~6.300 Hz	±1 dB
Séparation des canaux, AUX 1 kHz	50 dB
Niveau de sortie des casques et impédance	390 mV/330Ω
Impédance de charge	
PRINCIPALE ou AUXILIAIRE (MAIN or REMOTE)	4Ω~16Ω
PRINCIPALE et AUXILIAIRE (MAIN and REMOTE)	8Ω~16Ω

■ DIVERS

Consommation	310W
Alimentation	CA 50 Hz/60 Hz, 220V (Pour l'Europe)
	CA 50 Hz/60 Hz, 110V/120V/220V/240V (Autres)
Dimensions (L×H×Pr)	430 × 86 × 288 mm
Poids	5,8 kg

Nota:
La Société NATIONAL-PANASONIC-FRANCE, importateur du matériel MATSUSHITA-ELECTRIC déclare que cet appareil est conforme aux prescriptions de la directive 76/889/C.E.E. (arrêté 14 Janvier 1980).

Remarque:
1On mesure la distorsion harmonique totale au moyen d'un analyseur de spectre digital (Système H.P. 3045).

■ REGLAGES

Indicateurs de puissance de crête fluorescents

Réglage:

- Brancher un oscillateur à basse fréquence à la borne de sortie du tuner et une résistance de charge de 8 ohms et un voltmétre électronique à la borne de l'enceinte.
- Par l'oscillateur à basse fréquence, appliquer un signal de 1 kHz à l'appareil.
- Régler le volume du son au maximum.

Article	Position du commutateur de sélection de la gamme du compteur	VR à régler	Réglage
Indicateurs de puissance de crête fluorescents	Commutateur de gamme X0,01	VR601 (CG) VR602 (CD)	1. Régler le niveau de sortie de telle sorte que la voltmétre CA indique 2,0V. 2. Régler les résistances variables semi-fixes VR601 (canal de gauche) et VR602 (canal de droite), de façon à ce que le segment de 50W de l'appareil de mesure FL s'éclaire faiblement. (Fig. 14)

■ DISASSEMBLY INSTRUCTIONS

1. How to remove the cabinet

(1) Remove the 4 setscrews on the side and back of the cabinet. [Fig. 1: ❶ ~ ❹]
(2) Remove the cabinet from the chassis and rear panel as in Fig. 1.



[Fig. 1]



[Fig. 1-1]

2. How to remove the bottom board

(1) Remove the 3 setscrews [Fig. 2: ❺ ~ ❼] of the bottom board. [Screw ❼ is also used to fit the front panel.]
(2) Remove the setscrew [Fig.1-1: ⓭] of the printed circuit board.
(3) Lift the back [rear panel] of bottom board and remove claw Ⓒ from the rear panel.
(4) Lifting the back of bottom board, insert a flat-head screwdriver between the front chassis and bottom board as in Fig. 3 in order to remove claw Ⓐ.
(5) Remove the bottom board from the chassis.

3. How to fit the bottom board

(1) Insert the front of bottom board between the front chassis and front panel.
(2) Insert claw Ⓑ of board into claw hole Ⓑ of front chassis. [See Fig. 4]
(3) Insert claw Ⓒ of bottom board into claw hole Ⓒ of rear panel. [See Fig. 5.]
(4) Secure it with 4 setscrews.



[Fig. 2]



[Fig. 3]



[Fig. 4]



[Fig. 5]

4. How to remove the front panel

(1) Remove the 5 setscrews [Fig. 1: ❼ ~ ⓫] of front panel. [Screw ❼ is also used to fit the bottom board.]
(2) Stick an adhesive tape to bass, treble and balance knobs as in Fig. 1, then pull them off the front panel.



[Fig. 6]

5. How to remove the LED indicator P.C.B.

(1) Remove the LED indicator holder and push-button holder by use of a screwdriver, gaining access from the inside of chassis as shown in Fig. 6. [Remove the 5 claws of push-button holder.]
(2) Pull the P.C.B. toward the inside of chassis.

6. How to remove the FL meter P.C.B.

(1) Remove the front panel.
(2) Remove the setscrew ⓬ of meter range switch button as in Fig. 7.
(3) Push the FL holder claw in the direction of the arrow (➡) and then pull the P.C.B. backwards.
(4) Next, incline the P.C.B. in the direction of the arrow ① as in Fig. 8. Then pull it in the direction of the arrow ② to remove it from the chassis.

7. How to install the FL meter P.C.B.

*The P.C.B. can be installed by reversing the procedure for removal. Fit the FL as follows:
(1) Remove the FL filter. [Fig. 7]
(2) Fit the right and left sides of FL into the stopper of FL holder as in Fig. 9.
(3) Fit the P.C.B. in the original position.
(4) Set the FL filter in place.

8. How to remove the front chassis

*When replacing the push-button switches or the repairing the headphone jack P.C.B., remove the front chassis as follows:
(1) Remove the front panel.
(2) Remove the bottom board.
(3) Remove the LED indicator P.C.B. [See Fig. 6.]
(4) Remove the 3 setscrews [Fig. 10: ⓭ ~ ⓯] and the nut of headphone jack.
(5) Insert a screwdriver between the front chassis and the panel in order to remove claw Ⓐ as shown in Fig. 11.
(6) Remove the front chassis from the main P.C.B.
(3) Remove the nuts of bass, treble and balance knobs.
(4) Insert a falt-head screwdriver between the front panel and chassis in order to remove claw Ⓓ. [See Fig. 1.]
(5) Remove the front panel.



[Fig. 7]



[Fig. 8]



[Fig. 9]



[Fig. 10]



■ PROTECTION CIRCUITRY

The protection circuitry may have operated if either of the following conditions is noticed:

- No sound is heard when the power is turned on.
- Sound stops during performance.

The function of this circuitry is to prevent circuitry damage if, for example, the positive and negative speaker connection wires are "shorted", or if speaker systems with an impedance less than the indicated rated impedance of the amplifier are used.

If this occurs, follow the procedure outlined below:

1. Turn off the power.
2. Determine the cause of the problem and correct it.
3. Turn on the power once again.

Note:

When the protection circuitry functions, the unit will not operate unless the power is first turned off and then on again.

■ BEFORE REPAIR AND ADJUSTMENT

Turn off the power supply and short-circuit both ends of power supply condensers (401, C402, 6800μF) at resistance (about 10Ω, 5W) in order to discharge the charged voltage. Avoid short-circuit with a screwdriver or the like, otherwise the transistors or diodes may break down.

Before turning on the power supply after completion of repair, slowly apply the primary voltage by using a voltage regulator to make sure that the current consumed is free of abnormality. The current consumed at 60Hz/50Hz in no-signal mode is shown below with respect to supply voltage 110V/120V/220V/240V.

Power supply voltage		AC 110V	AC 120V	AC 220V	AC 240V
Current consumed	50Hz	210 ~ 310mA	190 ~ 290mA	100 ~ 200mA	90 ~ 190mA
	60Hz	200 ~ 300mA	180 ~ 280mA	90 ~ 190mA	80 ~ 180mA

■ TECHNICAL GUIDE

The power amplifier IC is provided with a protection circuit.

1. Muting (shock noise prevention) with power switch ON

(1) When power supply is turned ON, the voltage at point Ⓐ becomes negative due to power from D403 and D404, causing Q42 to turn ON.
(2) After lapse a few seconds, the charge voltage of C41 and C42 rises due to power from D414, then the voltage at point Ⓐ rises as well.
(3) Q42 turns OFF, and subsequently Q41 turns ON.
(4) Negative voltage is applied to IC21 and IC301, then the operation begins.

*The signal is applied to the power amplifier a few seconds later so that shock noise can be prevented.

2. Muting (shock noise prevention) with power switch OFF

(1) When power supply is turned OFF, the positive voltage at point Ⓐ is quickly discharged by D42, and then negative voltage remains.
(2) The negative voltage causes Q42 to turn ON, then Q41 turns OFF.

*The signal is cut off on the input side while the operation voltage of power amplifier still remains, thus preventing shock noise.

3. When over-load is connected to speaker terminals

(1) Due to over-load connected to the speaker terminal or excessive output, voltage is generated in R5 causing Q7 in power amplifier to turn ON which should be usually OFF.
(2) With Q7 ON, (I1) flows causing Q44 to turn ON.
(3) With Q44 ON, (I2) flows causing Q43 to turn ON.
(4) With Q43 ON, (I3) flows and Q44 ON is hold.
(5) The holding circuit functions to decrease the voltage at point Ⓐ, causing Q42 ON and Q41 OFF.

If no output is delivered due to the holding circuit, turn OFF the power supply to check the cause. After lapse a few minutes, turn ON the power supply. (The holdng circuit will not be reset soon.)

Voltage of point Ⓐ





[EG] is available in F.R. Germany.

• Input terminal circuit [EG] area only



• Volume control circuit

Change of resistor value
R201, 202 (2.7kΩ → 2.2kΩ)

Deletion of capacitor
C203, 204 (470pF → Deletion)

Additional parts



• Power source circuit [EG] area only





• Speaker terminal and speaker ground circuit [EG] area only





Printed in Japan
82039060 ⊗ KK

ESPAÑOL

■ ESPECIFICACIONES (Estas especificaciones están sujetas a cualquier cambio sin previo eviso.)

(DIN 45 500)

■ SECCION AMPLIFICADOR

Potencia continua de 20 Hz~20 kHz	2 × 35W (4Ω)
en ambos canales	2 × 35W (8Ω)
Potencia continua de 40 Hz~16 kHz	2 × 35W (4Ω)
en ambos canales	2 × 35W (8Ω)
Potencia continua de 1 kHz	2 × 40W (4Ω)
en ambos canales	2 × 40W (8Ω)
Distorsión armónica total	
potencia de régimen a 20 Hz~20 kHz	0,05% (4Ω)
	0,03% (8Ω)
potencia de régimen a 40 Hz~16 kHz	0,05% (4Ω)
	0,03% (8Ω)
potencia de régimen a 1 kHz	0,007% (4Ω), 0,005% (8Ω)
mitad de potencia a 20 Hz~20 kHz	0,03% (8Ω)
mitad de potencia a 1 kHz	0,005% (8Ω)
−26 dB de potencia a 1 kHz	0,01% (4Ω)
50 mW de potencia a 1 kHz	0,01% (4Ω)
Distorsión por intermodulación	
potencia de régimen a 250 Hz: 8 kHz=4:1, 4Ω	0,05%
potencia de régimen a 60 Hz: 7 kHz=4:1, SMPTE, 8Ω	0,03%
Ancho de banda de potencia	
con ambos canales, −3 dB	10 Hz~25 kHz (4Ω)
	10 Hz~25 kHz (8Ω)
Zumbido residual y ruido	0,6 mV
Factor de amortiguamiento	20 (4Ω), 40 (8Ω)
Sensibilidad e impedancia de entrada	
TOCADISC. (PHONO)	2,5 mV/47kΩ
SINTON., AUX. (TUNER, AUX)	150 mV/22kΩ
GRAB. 1 (TAPE 1)	150 mV/22kΩ
GRAB. 2 (TAPE 2)	150 mV/22kΩ
Voltaje máximo de entrada de PHONO (1 kHz, RMS)	150 mV
Respuesta de frecuencia	
TOCADISC. (PHONO)	curva RIAA estándar ±0,8 dB (30 Hz~15 kHz)
SINTON., AUX., GRAB. (TUNER, AUX, TAPE)	5 Hz~80 kHz (−3 dB)
Relación de señal a ruido	
potencia de régimen (4Ω)	
TOCADISC. (PHONO)	75 dB (IHF, A: 81 dB)
SINTON., AUX., GRAB. (TUNER, AUX, TAPE)	86 dB (IHF, A: 97 dB)
−26 dB de potencia (4Ω)	
TOCADISC. (PHONO)	65 dB
SINTON., AUX., GRAB. (TUNER, AUX, TAPE)	65 dB
50 mW de potencia (4Ω)	
TOCADISC. (PHONO)	62 dB
SINTON, AUX., GRAB. (TUNER, AUX, TAPE)	62 dB
Controles de tono	
BAJOS (BASS)	50 Hz, +10 dB~ −10 dB
AGUDOS (TREBLE)	20 kHz, +10 dB~ −10 dB
Control de sonoridad (volumen a −30 dB)	50 Hz, +9 dB
Voltaje de salida	
SAL. GRAB. (REC OUT)	150 mV
Equilibrio de canales, AUX 250 Hz~6.300 Hz	±1 dB
Separación de canales, AUX 1 kHz	50 dB
Impedancia y nivel de salida de los auriculares	390 mV/330Ω
Impedancia de carga	
MAIN o REMOTE/MAIN y REMOTE	4Ω~16Ω/8Ω~16Ω

■ GENERAL

Consumo de energía	310W
Requisito de energía	CA 50 Hz/60 Hz, 220V (Para Europa continental) CA 50 Hz/60 Hz, 110V/120V/220V/240V (Para otros paises)
Dimensiones (An.×Al.×Prof.)	430 × 86 × 288 mm
Peso	5,8 kg

Nota:
La distorsión armónica total se mide con el analizador de espectro digital (sistema H.P. 3045).

■ AJUSTES

Medidor fluorescente de potencia de cresta

Puesta

- Conectar un oscilador de baja frecuencia al terminal de entrada de sintonizador, y el resistor de carga 8-ohmios y voltímetro electrónico de CA al terminal del altavoz.
- Añadir señal 1kHz del oscilador de baja frecuencia al aparato.
- Poner el volumen de sonido al punto máximo.

Item	Posición de interruptor selector de gama de medidor	RV ajustado	Procedimiento de ajuste
Indicadores de potencia-cresta	Interruptor de gama ... X0.01	VR601 (Canal I) VR602 (Canal D)	1. Ajustar el nivel de entrada de manera que el voltímetro de CA indique 2 voltios. 2. Ajustar los resistores variables semifijos VR601 (C.I.) y VR602 (C.D.) de manera que el segmento de 50W del medidor FI se ilumine débilmente (Fig. 14)

■ CIRCUITS TO BE CHANGED AND THE AREAS

- Power source circuit [XA] area



[EF] area



[XA] area



[XL] area



Notes:

* [XA] is available in Southeast Asia, Oceania, Africa, Middle Near East and Central South America.
* S9 : Voltage selector in "240V" position.
  120V ⟷ 110V ⟷ 220V ⟷ 240V
* [EF] is available in France.
* [XL] is available in Australia.





[Fig. 11]



[Fig. 12]

9. How to remove the power IC

(1) Remove the cabinet and bottom board. (Refer to "How to remove the cabinet" and "How to remove the bottom board")
(2) Unsolder the power IC.
(3) Remove the 2 setscrews (Fig. 12: ⑯ , ⑰) used to secure the power IC on the heat-sink, and then pull out the power IC.
(4) When installing the power IC, apply heat diffusing agent (silicon powder, etc.) to back side of the IC, and secure it on the heat-sink with setscrews.

■ ADJUSTMENTS

Fluorescent peak power meter

Setting

- Connect a low frequency oscillator to the tuner input terminal, and 8-ohm load resistor and AC electronic voltmeter to the speaker terminal.
- Add 1kHz signal from the low frequency oscillator to the set.
- Set the sound volume to the maximum point.

Item	Meter range select switch position	VR adjusted	Adjustment
Peak-power indicators	Range switch ... X0.01	VR601 (L ch) VR602 (R ch)	1. Adjust the input level so that the AC voltmeter indicates 2 volts. 2. Adjust the semi-fixed variable resistors VR601 (L ch.) and VR602 (R ch.) so that the 50W segment of FL meter lights up dimly. (Fig. 14)

- **Adjustment points**



[Fig. 13]
[Abb. 13]

x 0.01 meter range
(8Ω, 2V output)

(Bass, Treble and Balance control to center)



[Fig. 14] [Abb. 14]

■ PRINTED CIRCUIT BOARDS

F PCB (FL meter circuit)

Ground (Earth) line



C PCB (Selector position LED indicators)



■ TERMINAL GUIDE OF TRANSISTORS, DIODES AND IC'S

SVINJM2043DD



SVIHA12010



AN7060F



SVISTK2038B



SVITA7318P



2SA564A, 2SA1015, 2SA1123, 2SC1384NC, 2SC1815



MA1200, SVDMZ306A



MA150, MA162A



SVDS2V20, SVDSR1K2



LN31GCPHL (Green)
LN41YCPHL (Yellow)




A
GROUND
PHONO
TUNER
AUX
TAPE 2
REC OUT
PLAYBACK
TAPE 1
REC OUT
PLAYBACK
Rch
MAIN
REMOTE
SPEAKERS
Lch
MAIN
REMOTE
S6 (remote)
S5 (main)
SPEAKERS
PHONES
L R
GND
AC LINE
Brown
Blue
GROUND POINT
Power transformer (T1)
B
(Equalizer circuit)
E
(Power mute & protection circuit)
D
(Voltage amplifier circuit)
IC301
IC1
IC21
Q20
Q41
Q42
Q43
Q44
Q401
Heat-sink
TH302 100K
100K TH301
To F P.C.B. (J3) terminal
To C P.C.B. (J2) terminal
VR201
VR201-2
VR201-1
VOLUME
phono
tuner
aux
tape 2 source
tape1/tape2 source
on
off
S1-1 (PHONO)
S1-2 (TUNER)
S1-3 (AUX)
INPUT SELECTOR
S3 (TAPE 2)
S2 (TAPE 1)
TAPE MONITOR
S4
LOUDNESS
VR202
BALANCE
VR301
VR301-1
VR301-2
TREBLE
VR302
VR302-1
VR302-2
BASS
F1 T1A
S8
POWER

■ BLOCK DIAGRAM





■ HOW TO REPLACE CHIPS (RESISTORS)



Fig. 1



Fig. 2

1. Unsolder from chip by using solder sucker.
2. Remove chip with tweezers by rotating it while removing solder as shown in Fig. 1.
3. Solder circuit board first and then solder chip in the direction of the arrow as shown in Fig. 2.

Notes:

1. Do not use chip again which is removed from printed circuit board.
2. Use lead wire with insulator for replacement instead of chip jumper.

- **Note for replacing chips**

1. Do not heat chips more than three (3) seconds.
2. Be careful not to damage the electrode of chips.
3. Use soldering iron (less than 60W) and tweezers for replacing chips.


SUP24830A
A
EQUALIZER CIRCUIT
B
IC1
SVINJM2043DD
EQUALIZER
SUP24313
L ch PHONO
GND
GROUND POINT
(For F.R. Germany)
R ch PHONO
TUNER
AUX
REC OUT
L ch TAPE 1
PLAYBACK
REC OUT
TAPE 2
PLAYBACK
TUNER
AUX
REC OUT
R ch TAPE 1
PLAYBACK
REC OUT
TAPE 2
PLAYBACK
INPUT SELECTOR
TAPE MONITOR
S1-1 (PHONO)
off → phono
S1-2 (TUNER)
off → tuner
S1-3 (AUX)
off → aux
S2 (TAPE 1)
source → tape 1/dubbing 1 → 2
S3 (TAPE 2)
source → tape 2
S4 (LOUDNESS)
off → on
SUP24830B
VOLUME
BALANCE
TREBLE
(Center open type)
BASS
VOLTAGE AMP CIRCUIT (Lch)
IC21
AN7060F
SUP24293
D
Q20
2SA1123
PRE DRIVE
D21
MA162A
VOLTAGE AMP (Rch)
This circuit is utterly same as above left channel.
SUP 24293
IC301
SVISTK2038B
2-CHANNEL POWER AMP
D301
SVDMZ306A
6V ZENER
D401 ~ 404
SVDS2V20
RECT
D407, 413, 414
SVDSR1K2
RECT
SUP24830C
C
D408 ~ 410
LN31GCPHL (U)
D411, 412
LN41YCPHLMS
D408 D409 D410
(phono) (tuner) (aux)
D411 D412
(tape 1) (tape 2)
D405, 406
MA1150M
15V ZENER
Q401
2SA564A
POWER OFF MUTE
−0.1V
0V
−0.7V
Power on
Power off
1 ~ 2s
Power on
Power off
0V
−30.7V
2 ~ 3s
4.3V
0V
−0.7V
E
Q41 ~ 43
2SA1015
SWITCHING/HOLD
Q44
2SC1815
HOLD
D41, 42
MA150
POWER MUTE
& PROTECTION CIRCUIT
SUP24471



* The part No. of transistors, IC and diodes mentioned in the schematic diagram stand for production part No. Regarding the part No. without ✪ mark, the production part No. are different from the replacement part No. Therefore, when placing an order for replacement parts, please use the part No. in the replacement parts list.

■ SCHEMATIC DIAGRAM

(This schematic diagram may be modified at any time with the development of new technology.)

Notes:

1. This is the basic circuit diagram (For continental Europe) of this unit.
   Note that part of the circuit is subject to change depending on the areas.
2. Regarding the circuits to be changed in the basic circuit diagram (For continental Europe) and related areas [EG], [EF], [XL] and [XA], refer to the separate service manual (Order No. SD82033214C8–A).
3. **S1-1 ~ S1-3:** Input selector switch in **"phono"** position.
   (S1-1: phono S1-2: tuner S1-3: aux)
4. **S2:** Tape monitor (tape 1) switch in **"source"** position.
   source ⟷ tape 1/dubbing 1 ▶ 2
5. **S3:** Tape monitor (tape 2) switch in **"source"** position.
   source ⟷ tape 2
6. **S4:** Loudness switch in **"off"** position.
7. **S5:** Main speaker switch in **"on (main)"** position.
8. **S6:** Remote speaker switch in **"off"** position.
9. **S7:** FL meter range selector switch in **"X1"** position.
   X1 ⟷ X0.01
10. **S8:** Power source switch in **"on"** position.
11. **S9 ([XA] area only):** Voltage selector switch in **"240V"** position. (Refer to booklet contain)
    120V ⟷ 110V ⟷ 220V ⟷ 240V
12. ▭ Indicated voltage values are the standard values for the DC electronic circuit tester (high impedance) with the ground point taken as standard. Therefore, there may exist some errors in the voltage values, depending on the internal impedance of the DC circuit tester.
13. **Description of "GROUND POINT"**
    The GND terminal of the rear panel and the chassis can serve as ground (earth) for signals. However, for direct current, they may sometimes fail to work as ground to check the DC voltage because they are connected to the ground line through 10Ω resistor – except for F.R. Germany [EG]. For DC voltage check, the "GROUND POINT" shown in "Printed circuit board" must be used.
14. ▒▒▒ Phono signal lines of left channel
15. ▬▶ Positive (+B) voltage lines
16. ▬▬▶ Negative (–B) voltage lines
17. Important safety notice:
    Components identified by ⚠ mark have special characteristics important for safety. When replacing any of these components, use only manufacturer's specified parts.

■ REPLACEMENT PARTS LIST

Notes: 1. Part numbers are indicated on most mechanical parts. Please use this part number for parts orders.
2. Important safety notice:
Components identified by ⚠ mark have special characteristics important for safety.
When replacing any of these components use only manufacturer's specified parts.
3. Bracketed indications in Ref. No. columns specify the area.
Parts without these indications can be used for all areas.
4. The "**S**" mark is service standard parts and may differ from production parts.
5. The parenthesized numbers in the column of description stand for the quantity per set.
6. **K** -marked parts are used for black only, while ○-marked parts are for silver type only.
7. Parts other than **K** - and ○- marked are used for both black ans silver types.

Black type model No. SU-Z45 (K)

Ref. No.	Part No.	Description
INTEGRATED CIRCUITS		
IC1	SVINJM2043DD	Equalizer
(IC21)x2	AN7060F	Voltage AMP.
IC301	SVISTK2038B	Power AMP.
IC601, 602	SVIHA12010	Level Comparator
IC603	SVITA7318P	Meter AMP.
TRANSISTORS		
(Q20)x2	2SA1123–R	Pre Drive
Q41~43	2SA1015–Y	Switching/Hold
Q44	2SC1815–Y	Hold
Q401 **S**	2SA722–S	LED Drive
Q601 **S**	2SC1384AR	Regulator
DIODES		
(D21)x2, 41, 42 **S**	MA162A	Switching
D301	SVDMZ306A	6V, Zener
D401~404 ⚠	SVDS2V20	Rectifier
D405, 406 **S**	MA1150A	15V, Zener
D407, 413, 414 ⚠ **S**	SVDSR1K2	Rectifier
D408~410	LN31GCPHL	Light Emitting Diode
D411, 412	LN41YCP	Light Emitting Diode
D601	MA1200	20V, Zener
COILS		
L101~104 (for [EG] only)	ELQS181KB	Output
L301, 302	SLQY15G–30	Choke
L321~324 (for [EG] only)	SLQY07G–30	Choke
TRANSFORMERS		
T1 other areas ⚠	SLT5M219	Power Source
T1 [EK, XL] ⚠	SLT5M221	Power Source
T1 [XA] ⚠	SLT5M223	Power Source
VARIABLE RESISTORS		
VR201	EWJG2A052B15	Volume, 100kΩ (B)
VR202	EWHFKA004G15	Balance, 100kΩ (G)
VR301	EWCX9A005012	Treble
VR302	EWCXAA005C15	Bass, 100kΩ(C)
VR601, 602	EVNK6AA00B23	FL Level Meter, 2kΩ(B)
THERMISTORS		
TH301, 302	RRT104	100kΩ
COMPONENT COMBINATION		
Z401	SXRFS203ZSM	(0.01μF) x 2
FLUORESCENT DISPLAY TUBE		
FL	SADBG89Z	Power Meter
FUSES		
F1 ⚠	XBA2C10TRO	250V, T1A
F2 [XA]only ⚠	XBA2C20TRO	250V, T2A
SWITCHES		
S1	SSH3033	Input Selector
S2, 3, 4	SSH3043	Tape Monitor, Loudness
S5, 6	SSH2017	Speaker (Main/Remote)
S7	SSH1053	Range Selector
S8 other areas ⚠	SSH1057	Power Source
S8 [E, EK] ⚠	ESB822S	Power Source
S8 [EG, XA] ⚠	ESB90217S	Power Source
S9 [XA]only ⚠	ESE37219	Voltage Selector

Ref. No.	Part No.	Description & Pcs
CABINET and CHASSIS PARTS		
1	SBN1089	Knob, Bass, Treble and Balance (3)
2 ○	SYW573	Front Panel Ass'y (Silver) (1)
2 **K**	SYW573–1	Front Panel Ass'y (Black) (1)
3	SBN1125	Knob, Volume (1)
4 ○	SGXUZ45E	Holder, Input Selector (Silver) (1)
4 **K**	SGXUZ45KE	Holder, Input Selector (Black) (1)
5 ○	SGXUZ45E1	Holder, Tape (Silver) (1)
5 **K**	SGXUZ45KE1	Holder, Tape (Black) (1)
6	SBC443	Button, Input Selector (3)
7	SBC445	Button, Tape Monitor (2)
8	SBC441	Button, Speaker, Range, Loudness (4)
9 ○	SDU131	Filter, FL (Silver) (1)
9 **K**	SDU131–1	Filter, FL (Black) (1)
10	SGX7327	Holder, FL (1)
11	SBC337–1	Button, Power Source (1)
12	SMX617	Shield Cover (1)
13 other areas	SMX609	Shield Cover (1)
13 [EG,XA] only	SMX453	Shield Cover (1)
14 (Except for[EG, XA])	SJT347	Holder, Fuse (2)
15	SJJ71B	Jack, Headphone (1)
16 ○	SKC1050S1	Cabinet (Silver) (1)
16 **K**	SKC1050B1	Cabinet (Black) (1)
17	SUS275	Bracket (1)
18	SMP323–1	Holder, LED (Tape) (1)
19	SMP321–1	Holder, LED (Input) (1)
20	SMX365	Shield Cover (1)
21 [EG] only	SJT347	Holder, Fuse (2)
21 [XA] only	SJT347	Holder, Fuse (4)
22 [XL] only	RJT202B	Terminal (1)
23	SML129	Bracket, Power Transformer (1)
23 [XL] only	SML129–1	Bracket, Power Transformer (1)
24	SMX615	Shield Cover (1)
25	SJF4815	Terminal Board (1)
26 other areas ⚠ **S**	SJA88	AC Cord (1)
26 [EK] ⚠	RJA45YA	AC Cord (1)
26 [XA] ⚠	SJA111	AC Cord (1)
26[XL] ⚠ **S**	QFC1207MA	AC Cord (1)
27 other areas	SHR127	Bushing, AC Cord (1)
27 [EK] only	SHR129	Bushing, AC Cord (1)
27 [XL] only	SHR131	Bushing, AC Cord (1)

Ref. No.	Part No.	Description & Pcs
28 other areas	SGP3170B	Rear Panel (1)
28 [EK] only	SGPUZ45E	Rear Panel (1)
28 [XA] only	SGP3170–1A	Rear Panel (1)
28 [XL] only	SGP3170–2A	Rear Panel (1)
29 ⚠ [XA] only	SJS601–2	Socket (1)
30	SJF3051–3N	Terminal Board (1)
31	SHR401–1	Look Pin (1)
32	SKUUZ45E	Bottom Board (1)
33	SKL249	Foot (4)
SCREWS		
N1	XTBS3+8BFYR1	Tapping, with Detent (3)
N2 **S**	XTB3+8BFN	Tapping, ⊕ 3x8 (5)
N3 **S**	XSN3+6S	⊕ 3x6 (4)
N4 ○	SNE2095–2	Tapping (2)
N4 **K**	SNE2095–3	Tapping (2)
N5 **S**	XTB4+10BFZ	Tapping, ⊕ x 10 (4)
N6 **S**	XSN3+12BNS	⊕ 3x12 (2)
N7 **S**	XTN3+8B	Tapping, ⊕ 3x8 (1)
N7 [EG] only	XTWS3+8HFZ	Tapping, ⊕ 3x8 (1)
N8 **S** [XL] only	XTB3+8BFN	Tapping, ⊕ 3x8 (1)
N9 **S** ○	XTB3+8BFN	Tapping, ⊕ 3x8 (2)
N9 **S** **K**	XTB3+8BFZ	Tapping, ⊕ 3x8 (2)
N10	XTBS3+8BFZ1	Tapping, with Detent (10)
N12	XTBS3+8BFYR1	Tapping, with Detent (2)
N13 **S**	XTN3+10B	Tapping, ⊕ 3x10 (4)
WASHERS		
N14 **S**	XWA3B	Spring, φ3 (6)
N15 **S**	XWG3	Plain, φ3 (7)
N16 **S** [XL] only	XWC3B	External Toothed Lock φ3 (2)
N17 **S**	XWC3B	External Toothed Lock φ3 (2)
NUTS		
N18	SNE4021	Nut, with Plain (4)
N19 **S**	XNS12	φ12 (1)
ACCESSORIES		
A1 ⚠ [XA] only	SJP5213–1	Plug Adapter, (C → U) (1)
A2 ⚠ [XA] only	SJP5215	Plug Adapter, (U → B) (1)
A3 [E,EH,EB]	SQF11213	Instructions Book (1)
A3 [EG]	SQF11215	Instructions Book (1)
A3 [EK, XL]	SQF11217	Instructions Book (1)
A3 [EF]	SQF11219	Instructions Book (1)
A3 [XA]	SQF11221	Instructions Book (1)
A3 [Ei]	SQF11363	Instructions Book (1)
PACKING PARTS		
P1 ○	SPP699	Polyethylene Bag (Silver) (1)
P1 **K**	SPP649	Polyethylene Bag (Black) (1)
P2 other areas	SPS3661–2	Pad, Left Side (1)
P2 [XL] only	SPS3661–1	Pad, Left Side (1)

■ EXPLODED VIEW



Ref. No.	Part No.	Description & Pcs
P3 other areas	SPS3663	Pad, Right Side (1)
P3 [XL] only	SPS3663–1	Pad, Right Side (1)
P4 other ○ areas	SPG3895	Carton Box (Silver) (1)
P4 [EF] ○	SPG3897	Carton Box (Silver) (1)
P4 [Ei] ○	SPG3899	Carton Box (Silver) (1)
P4 [XL] ○	SPG3901	Carton Box (Silver) (1)
P4 [E] **K**	SPG3991	Carton Box (Black) (1)
P4 [EG] **K**	SPG3993	Carton Box (Black) (1)
P4 **K** [EH, Ei]	SPG3995	Carton Box (Black) (1)

Areas

* [E] is available in Scandinavia and Switzerland.
* [EG] is available in F.R. Germany.
* [EK] is available in United Kingdom.
* [EF] is available in France.
* [EH] is available in Holland.
* [EB] is available in Belgium.
* [Ei] is available in Italy.
* [XA] is available in Southeast Asia, Oceania, Africa, Middle Near East and Central South America.
* [XL] is available in Australia.

• Accessories





■ RESISTORS & CAPACITORS

Notes:
1. Part numbers are indicated on most mechanical parts. Please use this part number for parts orders.
2. Important safety notice: Components identified by ⚠ mark have special characteristics important for safety. When replacing any of these components use only manufacturer's specified parts.
3. Bracketed indications in Ref. No. columns specify the area. Parts without these indications can be used for all areas.
4. The "**S**" mark is service standard parts and may differ from production parts.
5. Unless otherwise specified.
   All resistors are in OHMS (Ω) K = 1000Ω, M = 1000kΩ
   All capacitors are in MICROFARADS (μF) P = μμF

Numbering System of Resistor

Example

ERD	25	F	J	101
Type	Wattage	Shape	Tolerance	Value

Resistor Type	Wattage	Tolerance
ERD : Carbon	10 : 1/8W	G : ± 2%
ERG : Metal Oxide	25 : 1/4W	J : ± 5%
ERO : Metal Film	1 : 1W	
	S1 : 1/2W	

ERD10TLJ□□□ ⟶ Chip type carbon
ERO10MKG□□□ ⟶ Chip type metal film

Numbering System of Capacitor

Example

ECKD	1H	103	Z	F	ECEA	50	M	R47	R
Type	Voltage	Value	Tolerance	Peculiarity	Type	Voltage	Peculiarity use	Value	Special use

Capacitor Type	Voltage: ECEA Type	Voltage: Others	Tolerance
ECEA : Electrolytic	1A : 10V	1H : 50V DC	C : ± 0.25pF
ECEA...N : Non Polar Electrolytic	1C : 16V	2H : 500V DC	J : ± 5%
ECCD : Ceramic	1E : 25V	MY : 125V AC	K : ± 10%
ECKD : Ceramic	1V : 35V	KC : 400VAC	M : ±20%
ECQM : Polyester	1H : 50V	2A : 250VAC	Z : +80%, –20%
ECQE : Polyester	1J : 63V		P : +100%, –0%
ECET : Electrolytic	50 : 50V		
	25 : 25V		
	2A : 100V		

Ref. No.	Part No.	Value
RESISTORS		
R1, 2	ERD10TLJ391U	390
R3, 4	ERO10MKG2213	221K
R5, 6	ERO10MKG5622	56.2K
R7, 8	ERD10TLJ271U	270
R9, 10	ERD10TLJ680U	68
R11, 12	ERD10TLJ184U	180K
R13, 14	ERD10TLJ123U	12K
R15, 16	ERD10TLJ563U	56K
R17, 18	ERD10TLJ102U	1K
(R21)x2	ERD10TLJ102U	1K
(R22)x2	ERD10TLJ124U	120K
(R23)x2	ERD10TLJ393U	39K
(R24)x2	ERD10TLJ823U	82K
(R25)x2	ERD10TLJ561U	560
(R28)x2	ERD10TLJ681U	680
R41	ERD10TLJ124U	120K
R42	ERD10TLJ563U	56K
R43	ERD10TLJ471U	470
R44	ERD10TLJ103U	10K
R45	ERD10TLJ222U	2.2K
R46	ERD10TLJ473U	47K
R48	ERD10TLJ562U	5.6K
R56	ERD10TLJ333U	33K
R101, 102 **S** (for [EG] only)	ERD25FJ391	390
R103, 104 **S** (for [EG] only)	ERD25FJ272	2.7K
R105~112 **S** (for [EG] only)	ERD25FJ102	1K
R151 **S** (Except for [EG])	ERD25FJ100	10
R153, 154 **S**	ERD25FJ101	100
R201, 202 S (Except for [EG])	ERD25FJ272	2.7K
R201, 202 S (for [EG] only)	ERD25FJ222	2.2K

Ref. No.	Part No.	Value
R203, 204 **S**	ERD25TJ223	22K
R205, 206 **S**	ERD25TJ473	47K
R301, 302 **S**	ERD25FJ122	1.2K
R303, 304 **S**	ERD25TJ824	820K
R305, 306 **S**	ERD25TJ223	22K
R307, 308 **S**	ERD25FJ392	3.9K
R309, 310 **S**	ERD25TJ683	68K
R311, 312 **S**	ERD25FJ392	3.9K
R313, 314 ⚠ **S**	ERD25FJ470	47
R315 ⚠ **S**	ERD25FJ470	47
R316 **S**	ERG1ANJ152	1.5K
R317, 318 **S**	ERD25FJ272	2.7K
R319, 320 **S**	ERD25FJ222	2.2K
R321, 322 ⚠	ERDS1FJ100	10
R323, 324 **S**	ERG1ANJ331	330
R410, 402 ⚠	ERDS1FJ152	1.5K
R403, 404 **S**	ERD25TJ153	15K
R406, 407 **S**	ERD25FJ151	150
R411 **S**	ERG1ANJ152	1.5K
R414 ⚠ **S**	ERD25FJ390	39
R415 ⚠ **S**	ERD25FJ470	47
R416 **S**	ERD25TJ274	270K
R417 **S**	ERD25FJ122	1.2K
R601, 602 **S**	ERD25FJ682	6.8K
R603, 604 **S**	ERD25FJ821	820
R605, 606 **S**	ERD25TJ223	22K
R607 ⚠	ERDS1FJ271	270
R608 ⚠ **S**	ERD25FJ561	560
R609 **S**	ERD25FJ472	4.7K
R610 ⚠	ERDS1FJ151	150
R611 **S**	ERD25FJ471	470
R612 ⚠	ERDS1FJ391	390

Ref. No.	Part No.	Value
CAPACITORS		
C1, 2 **S**	ECEA50M3R3R	3.3
C3, 4 **S**	ECCD1H101KC	100P
C5, 6 **S**	ECKD1H471KB	470P
C7, 8 **S**	ECQM1H223JZ	0.022
C9, 10 **S**	ECQM1H682JZ	0.0068
C11, 12 ⚠	ECEA1HN010S	1
C13, 14 **S**	ECEA1CS330	33
(C21)x2 **S**	ECEA50Z3R3	3.3
(C22)x2 **S**	ECCD1H390KC	39P
(C23)x2 **S**	ECEA1HS100	10
(C24)x2 **S**	ECEA25Z4R7	4.7
(C28)x2 **S**	ECCD1H820K	82P
(C29)x2 **S**	ECCD1H030CC	3P
(C30)x2 **S**	ECCD1H330KC	33P
(C31)x2 **S**	ECCD1H391KB	390P
C41 **S**	ECEA1JS330	33
C42, 43 **S**	ECEA1HS470	47
C44 **S**	ECEA2AS3R3	3.3
C101, 102 **S** (for [EG] only)	ECCD1H180KC	18P
C201, 202 **S**	ECQM1H563JZ	0.056
C203, 204 **S** (Except for [EG])	ECKD1H471KB	470P
C221 ~ 228 **S** (for [EG] only)	ECKD1H471KB	470P
C301, 302 **S**	ECQM1H223JZ	0.022
C303, 304 **S**	ECQM1H183JZ	0.018
C305, 306 **S**	ECQM1H104JZ	0.1
C307 **S**	ECEA1HS101	100
C308 **S**	ECKD1H103ZF	0.01
C311, 312 **S**	ECCD1H101KC	100P
C313, 314 **S**	ECCD1H101KC	100P
C315, 316 **S**	ECEA1HS470	47
C317, 318 ⚠	ECEA1EN3R3S	3.3
C319, 320 **S**	ECQM1H473JZ	0.047
C321~324 **S** (for [EG] only)	ECKD1H103ZF	0.01

Ref. No.	Part No.	Value
C325, 326 **S** (for [EG] only)	ECKD1H333ZF	0.033
C391, 392 (for [EG] only)	ECQM1H124KZ	0.12
C393 **S** (for [EG] only)	ECKD1H333ZF	0.033
C401, 402	ECETS45V682U	6800
C403 **S**	ECEA1AS331	330
C404 **S**	ECEA2AS100	10
C407, 408 **S**	ECEA1ES101	100
C409, 410 **S**	ECKD1H103ZF	0.01
C501 ⚠ (Except for [EG] & [XA])	ECKDKC103PF	0.01
C502 ⚠ (for [EF] only)	ECQE2A473MW	0.047
C503~506 ⚠ (for [EG] only)	ECKDKC222MF	0.0022
C507 ⚠ (for [EG] only)	ECQE2A473MW	0.047
C508, 509 ⚠ (for [EG] & [XA] only)	ECKDKC103PF	0.01
C601, 602 **S**	ECEA50ZR47	0.47
C603 **S**	ECEA50ZR47	0.47
C604 **S**	ECKD1H103ZF	0.01
C605, 606 **S**	ECKD1H332KB	0.0033
C609 **S**	ECEA1VS330	33

• Accessories



Foot view of left rear



Printed in Japan
820310500®KK/TN